



How to change front anti  
roll bar links on **BMW**  
**E92** – replacement guide

## VIDEO TUTORIAL



### **i Important!**

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 3 Touring (E91) 318i 2.0, BMW 3 Touring (E91) 316d 2.0, BMW Z4 Roadster (E89) sDrive 20 i, BMW Z4 Roadster (E89) sDrive 28 i, BMW 1 Coupe (E82) 118d 2.0, BMW 3 Coupe (E92) 318i 2.0, BMW 3 Convertible (E93) 318i 2.0, BMW 3 Convertible (E93) 325d 3.0, BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, (+ 89)

The steps may slightly vary depending on the car design.

## REPLACEMENT: ANTI ROLL BAR LINKS – BMW E92.

### LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #16
- Combination spanner #17
- Drive socket # 16
- Drive socket # 17
- HEX bit No.H5
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

**BUY TOOLS**


### AUTODOC recommends:

- Replace the stabiliser links on BMW E92 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: ANTI ROLL BAR LINKS – BMW E92. RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.

2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the front of the car and secure on supports.




4 Unscrew the wheel bolts.




AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. BMW E92


5 Remove the wheel.




6.1 Clean the stabiliser link fasteners.




6.2 Use a wire brush. Use WD-40 spray.




- 7** Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use a drive socket #17. Use a ratchet wrench.



- 8** Disconnect the brake hose mounting bracket.



- 9** Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use a combination spanner #17.



- 10** Remove the stabilizer rod.




Replacement: anti roll bar links – BMW E92. Professionals recommend:

- Examine stabiliser bushes. Replace them if needed.


11

Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




12

Install a new rod, tighten the fasteners.




13

Install the bracket onto the shock absorber strut.






- 14 Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use HEX No.H5. Use a drive socket #16. Use a torque wrench. Tighten it to 58 Nm torque.



- 15 Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #16. Use HEX No.H5. Use a drive socket #16. Use a torque wrench. Tighten it to 58 Nm torque.



- 16 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



- 17 Clean the brake disk surface. Use a brake cleaner.





### AUTODOC recommends:

- Replacement: anti roll bar links – BMW E92. After applying the spray, wait a few minutes.

18

Install the wheel.




### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E92


19

Screw in the wheel bolts. Use wheel impact socket #17.



20

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



21

Remove the jacks and chocks.



**WELL DONE!** 

**VIEW MORE TUTORIALS**


## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
 **Google Play**

 **Download on the App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BUY SPARE PARTS FOR BMW**

**ANTI ROLL BAR LINKS: A WIDE SELECTION**

**CHOOSE CAR PARTS FOR BMW E92**

**ANTI ROLL BAR LINKS FOR BMW: BUY NOW**

**ANTI ROLL BAR LINKS FOR BMW E92: THE BEST DEALS & OFFERS**

### **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.